


RI360P0-QR24M0-1000X2-H1181 Contactless Encoder – Incremental: 1000 ppr Premium Line






Technical data

Туре	RI360P0-QR24M0-1000X2-H1181	
ID	1593153	
Measuring principle	Inductive	
General data		
Max. rotational speed	9000 rpm	
	Determined with standardized construction, with a steel shaft \emptyset 20 mm, L = 50 mm and reducer \emptyset 20 mm.	
Starting torque shaft load (radial / axial)	not applicable, because of contactless measuring principle	
Nominal distance	1.5 mm	
Repeat accuracy	≤ 0.01 % of full scale	
Linearity deviation	≤ 0.05 % f.s.	
Temperature drift	≤ ± 0.003 %/K	
Output type	Incremental	
Resolution incremental	1000 ppr	
Electrical data		
Operating voltage U _B	1030 VDC	
Ripple U _{ss}	≤ 10 % U _{Bmax}	
Isolation test voltage	0.5 kV	
Short-circuit protection	yes/Cyclic	
Wire break/reverse polarity protection	yes/yes (voltage supply)	
Pulse frequency max.	200 kHz	
Signal level high	min. U _B - 2 V	
Signal level low	max. 2.0 V	
Output function	8-pin, Push-Pull/HTL	
Sample rate	1000 Hz	

Features

- Compact, rugged housing
- Many mounting possibilities
- Status displayed via LED
- Immune to electromagnetic interference
- Position of z-track can be set via Easy-Teach
- ■Burst function, absolute angular position output incrementally via Easy-Teach pulse
- ■10...30 VDC
- Male M12 x 1, 8-pin
- Push-pull A, B, Z, A (inverse), B (inverse)

Wiring diagram





Functional principle

The measuring principle of inductive angle sensors is based on oscillation circuit coupling between the positioning element and the sensor, whereby an output signal is provided



Technical data

Current consumption	< 100 mA	
Mechanical data		
Design	QR24	
Dimensions	81 x 78 x 24 mm	
Flange type	Flange without mounting element	
Shaft Type	Hollow shaft	
Shaft diameter D (mm)	6 6.35 9.525 10 12 12.7 14 15.875 19.05 20	
Housing material	Metal/plastic, ZnAlCu1/PBT-GF30-V0	
Electrical connection	Connector, M12 × 1	
Environmental conditions		
Ambient temperature	-25+85 °C	
	Acc. to UL approval to +70 °C	
Vibration resistance	55 Hz (1 mm)	
Vibration resistance (EN 60068-2-6)	20 g; 103000 Hz; 50 cycles; 3 axes	
Shock resistance (EN 60068-2-27)	100 g; 11 ms ½ sine; 3 × each; 3 axes	
Continuous shock resistance (EN 60068-2-29)	40 g; 6 ms ½ sine; 4000 × each; 3 axes	
Protection class	IP68 IP69K	
MTTF	138 years acc. to SN 29500 (Ed. 99) 40 °C	
Power-on indication	LED, Green	
Measuring range display	LED, yellow, yellow flashing	
Included in delivery	MT-QR24 mounting aid	
UL certificate	E210608	


proportional to the angle of the positioning element. The rugged sensors are wear and maintenance-free, thanks to the contactless operating principle. They convince through their excellent repeatability, resolution and linearity within a broad temperature range. The innovative technology ensures a high immunity to electromagnetic DC and AC fields.




Mounting instructions

Mounting instructions/Description


A




0.6...0.8 Nr SP2-QR24








B



M4 x 0.5 x 7.5

Default: 0°



Extensive range of mounting accessories for easy adaptation to many different shaft diameters. Based on the functional principle of RLC coupling, the sensor operates absolutely wear-free and is immune to magnetized metal splinters and other interference fields. Wrong installation is hardly possible.

The adjacent figure shows the two separate units, sensor and positioning element.

Mounting option A:

First, interconnect positioning element and rotatable shaft. Then place the encoder above the rotating part in such a way that you get a tight and protected unit.

Mounting option B:

Push the encoder on the back site of the shaft and fasten it to the machine. Then clamp the positioning element to the shaft with the bracket.

Mounting option C:

If the positioning element is to be screwed on a rotating machine part, use the RA0-QR24 plug which is included in the delivery. Then tie up the bracket. Screw on the encoder via the three bores.

The separately arranged sensor and positioning element inhibit that compensating currents or damaging mechanical loads are transmitted via the shaft to the sensor. In addition, the encoder remains tight and highly protected during its entire lifespan.

The accessories enclosed in the delivery help to mount encoder and positioning element at an optimal distance from each other. LEDs indicate the switching status.

Status display via LED green steady:

Optimal sensor supply

yellow steady:

Positioning element has reached the end of the measuring range. This is indicated by a lower signal quality.

yellow flashing:

Positioning element is outside the measuring range.

off:

Positioning element is in the measuring range.


Individual Parameterization (Teaching with Positioning Element)


individual Parameterization (Teaching with Positioning Element)			
Jumper between teach	Gnd Pin 1	Ub Pin 2	LED
input Pin 8			
2 s	Z-track zero point	One-time triggering of burst	Status LED flashes then
	teaching	function	turns steady after 2 s
10 s	CCW rotation	CW rotation direction	After 10 s status LED
	direction		flashes fast for 2 s
15 s	-	Factory setting (z-track, CW)	After 15 s power and
			status LED alternate

To avoid unintended teaching, keep pin 8 potential-free.


TURCK

Accessories





Accessories





Accessories

